

Time/Date Programming For DSC Control Panel

Control Panel	Required Keypad Entry
PC500	No time/date programming required
PC550	No time/date programming required
PC580	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1000	No time/date programming required
PC1150	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1500	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1550	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1555(MX)	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1575	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>

PC2500	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC2525	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC2550	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC3000	<p>Step 1 – Enter time programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC4000	<p>Step 1 – Enter time programming by pressing [Master Code] + [] + [4] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC4010	<p>Step 1 – Enter time programming by pressing [Master Code] + [9] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC4020	<p>Step 1 – Enter time programming by pressing [Master Code] + [9] + [1] Step 2 – Enter [HH:MM] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>

PC5010	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC5020	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1616	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1832	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
PC1864	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
SCW9045/9047	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>
ALEXOR (PC9155)	<p>Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1] Step 2 – Enter [HH:MM] [MM/DD/YY] Step 3 – Press [#] to exit</p> <p>Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)</p>

ENVOY 9005/9010

Step 1 – Enter time/date programming by pressing [*][6] + [Master Code] + [1]

Step 2 – Enter [HH:MM] [MM/DD/YY]

Step 3 – Press [#] to exit

Note: Program the time using military standard (e.g. 8:00 pm = 20:00 hours)