

KEY CONTROLS AND INDICATORS

STEP 1

Connect the AC Adapter into the DC 7.5 Volt Jack on the back of the console. Plug the Adapter into an electrical outlet that is NOT controlled by a light switch.

STEP 2

Turn the ON/OFF switch on the underside of the console to the ON position.

STEP 3

Plug the phone cord into Jack A on the back of the console and the other end into the wall jack. If you need to plug in a house phone in the same vicinity, plug it into Jack B.

STEP 4

TEST THE SYSTEM. Press the BLUE button on the front of the pendant for at least four (4) seconds. You will hear a series of beeps and a dialing sound, then 30-60 seconds of silence, and an operator will come on and ask if you are ok. Simply say you are making a test call, and the operator will ask you a few questions to set up your account properly.

TEST MONTHLY:

If you do not get a successful test call, call Advanced Alarms, Ltd at 1-800-572-2703 for assistance.

DSL - Requires a filter between telephone jack and phone cord or telephone line splitter.

VOIP - May require special equipment. Please contact us if needed.

PENDANT

Blue Call Button

Press for 4 seconds to initiate a call

Battery Compartment

Twist left to open, insert a 3.7v Li-ion rechargeable battery positive side down. Close by twisting to the right until tight. Put other battery in the Console charger. NOTE: These are NOT AAA batteries.

LED Indicator

Flashes red when pendant is activated.



Gray Test Button (back)

Press to test system and battery or to hang up from a call.

CONSOLE

Speaker

Power Indicator

Solid red when power is on. Flashes red when running on battery power.




Info Indicator

Solid green when pendant is in use. Flashes green when battery is low or pendant is learning.

Pendant Battery Charging Compartment

Light is RED when battery is charging, GREEN when fully charged, and OFF when battery is not detected in charger.



Line In from Wall (Jack A)

Line Out to Telephone (Jack B - Optional)

Mode Switch

AC Adapter Input

Notes about your system:

- 1) Do a system check at least every two weeks. Press the Gray Test button for FOUR seconds. After a few seconds, you should hear a dial tone and the announcement "All systems are OK." You will also hear a battery status check.
- 2) When you put a battery in the charger to charge, make sure the indicator light glows RED. Red means the battery is actually getting charged.

ONE YEAR LIMITED WARRANTY

How to Get Warranty Service: All warranty service must go through your dealer or service provider. If for some reason this is not doable, then the original consumer/purchaser can return the product pre-paid to LogicMark, LLC; 10106 Bluegrass Pkwy; Louisville KY, 40299, USA within the warranty period, and if the product is defective, LogicMark, LLC will at its option repair or replace such.

LogicMark, LLC warrants to the original consumer/purchaser that this product shall be free of defects in material and workmanship under normal use for a period of one (1) year from the date of original purchase.

Warranty Limitations and Exclusions: LogicMark, LLC does not warrant that this System will prevent any loss, damage or injury to person or property, or that the personal emergency alert system will in all cases provide the protection for which it is installed or intended. Purchaser acknowledges that LogicMark, LLC is not an insurer, and that Purchaser assumes all risk for loss or injury to Purchaser's property or person. LogicMark, LLC has made no representation or warranties, except those expressed herein and hereby disclaims any express warranty of merchantability or fitness for any particular use.

LogicMark, LLC will not be responsible for the improper use of this System, nor will it be responsible for failure resulting from the use of other equipment connected to the same phone line. We will not be responsible for the quality of the phone line or the reliability or quality of the phone service with which the System is used. LogicMark, LLC will not be responsible for the installation of the System. It will not be responsible for the improper use or abuse of the console or pendant.

OUT OF WARRANTY REPAIRS

As with all warranty repairs - you need to work through your dealer or service provider. If the warranty period has expired or if you are not the original owner of the product, LogicMark, LLC will at its option either (1) replace this product with a functionally similar (but not necessarily identical) refurbished product or (2) repair the original product and return it to the subscriber after payment has been received.